



Module labeling

Important:

Every time a set of modules is being initialized a sticker has to be put on each of the 4 modules of this set containing the following information:

set = {set number} (a set is a group of 4 disks, so e.g. set=1)
slot= {slot number}
station = {station code} (eg. for Pico it is PV)

{slot number} should indicate the slot the module has been in upon initialization

{set number}: should be identical for all four modules. The first 4 modules to be used in the observations should receive set number=1, in case a second (or third) set of modules will be used later during the observations these should receive an incremented set number (e.g. 2, 3, ...)

{station code}: the two letter station code

If you ever re-initialize the modules, update the stickers!