



Module change

When changing a set of modules follow this procedure:

Close the group

login to Mark6 as user oper,

then type command:

```
>da-client
```

in da-client execute:

```
group=close:1234
```

Unmount the group

```
group=unmount:1234  
mstat?all
```

all 4 modules should now have the state "unmounted", e.g.:

```
!mstat?0:0:1234:1:MPIH%008/48008/4/8:8:8:47536:48008:unmounted:unprotected
```

Remove the modules

Before you remove the modules make sure each of the modules has a label sticker on and the information on it are correct. If not follow this [procedure](#) to label the modules.

Do this one slot at a time:

- Turn the key on the mark6 into the vertical position. Wait until all LEDs except the first LED ("Present") on the slot turn off.
- Remove the miniSAS cables by pulling the blue latch of the connector.
- Remove the module from the slot

You can now enter a new set of modules. Follow the procedure described [here](#) to continue with the observations.